



DRIVER TAG REGISTRATION & USAGE GUIDE

1 Register Driver RFID into Driver Module in System

Management -> Driver Module -> Add Driver



4 Go to Smartfleet Drop down menu to enable the viewing option for Driver/ RFID Tag



2 Distribute RFID Tag to Driver

3 Driver Required to tagged the RFID Reader before they start Engine for New Trip



5 Go to Driver Module to View Driver Login



MALAYSIA

Gussmann Technologies Sdn. Bhd.

51-3, Jalan 5/18A, Taman Mastiara,
Batu 5 1/2 Jalan Ipoh, 51200, Kuala Lumpur,
Wilayah Persekutuan, 51200

Contact : +603 6257 0509
E-mail : info@g1.com.my
Website : g1.com.my

PHILIPPINES

Gussmann Integrated Solution Phil. Inc

Room 607 Royal Plaza Towers,
#648 Remedios St. cor Guerrero St. Malate,
Manila

Contact : +63(02) 554 0558
E-mail : info@gussmann.ph
Website : g1.com.my